
INSTALLATION, OPERATION, PARTS LIST, AND MAINTENANCE MANUAL

GORMAN-RUPP
OM-01046-0B06

CD

March 10, 1980 REV. B





INSTALLATION

This Installation, Operation, and Maintenance Manual is designed specifically to help you get the best performance and longest life from your Gorman-Rupp pump.

This pump is a T Series, semi-open impeller, self-priming centrifugal model. It is designed for sewage, wastewater, trash, and industrial applications.

If there are any questions regarding the pump which are not covered in this manual or in other literature accompanying the unit, please contact your Gorman-Rupp distributor, or write:

The Gorman-Rupp Company

Gorman-Rupp of Canada Limited

P.O. Box 1217

70 Burwell Road

Mansfield, Ohio 44902

St. Thomas, Ontario N5P 3R7

For information or technical assistance on the power source, contact the power source manufacturer's local dealer or representative.

The following are used to alert maintenance personnel to procedures which require special attention, to those which could damage equipment, and to those which could be dangerous to personnel:

NOTE

Instructions to aid in installation, operation, or maintenance or which clarify a procedure.

CAUTION

Instructions which must be followed to avoid causing damage to the product or other equipment incidental to the installation. These describe the procedure required and the damage which could result from failure to follow the procedure.

WARNING

Instructions which must be followed to avoid causing injury or death to personnel. These describe the procedure required and the injury which could result from failure to follow the procedure.

TABLE OF CONTENTS

WARNINGS Section A
INSTALLATION Section B
OPERATION Section C
TROUBLESHOOTING Section D
MAINTENANCE AND REPAIR Section E
WARRANTY



WARNINGS

THESE WARNINGS APPLY TO ALL BASIC PUMPS. GORMAN-RUPP HAS NO CONTROL OVER OR PARTICULAR KNOWLEDGE OF THE POWER SOURCE WHICH WILL BE USED. REFER TO THE MANUAL ACCOMPANYING THE POWER SOURCE BEFORE ATTEMPTING TO START THE POWER SOURCE.

Before attempting to open or service the pump: 1. Familiarize yourself with this manual. 2. Disconnect the power source to ensure that the pump will remain inoperative. 3. Allow the pump to cool if overheated. 4. Vent the pump slowly and cautiously. 5. Close the suction and discharge valves. 6. Check the temperature before opening any covers, plates, or plugs. 7. Drain the pump. Do not attempt to pump volatile or corrosive materials for which this pump has not been designed. After the pump has been located in its operating position, make certain that the pump has been secured before attempting to operate it. Do not operate the pump without shields and/or guards in place over drive shafts, belts and/or couplings, or other rotating parts. Exposed rotating parts can catch clothing, fingers, or tools, causing severe injury to personnel. Do not operate the pump against a closed discharge valve for long periods of time. This could bring the liquid to a boil, build pressure, and cause the pump to rupture or explode.



Overheated pumps can cause severe burns and injury. If overheating of the pump casing occurs:

- 1. Stop the pump immediately.
- 2. Allow the pump to cool.
- 3. Refer to instructions in this manual before restarting the pump.

Do not remove plates, covers, gauges, pipe plugs, or fittings from an overheated pump. Vapor pressure within the pump can cause parts being disengaged to be ejected with great force. Allow the pump to cool before servicing.

This pump is designed to pump materials which could cause serious illness or injury through direct exposure or emitted fumes. Wear protective clothing, such as rubber gloves, face mask, and rubber apron, as necessary before disassembling the pump or piping.

Page 2 Section A.



INSTALLATION

Seldom are two pump installations identical. The information presented in this section is a summary of the recommended installation practices related to inspection, pump positioning, hardware, suction and discharge piping, and sumps. For further assistance, contact your Gorman-Rupp distributor or the Gorman-Rupp Company.

PREINSTALLATION INSPECTION

The pump assembly was inspected and tested before it was shipped from the factory. Before installation, inspect the pump for damage which may have occurred during shipment. Check as follows:

- a. Inspect the pump assembly for cracks, dents, damaged threads, and other obvious damage.
- b. Check for and tighten loose bolts, nuts, cap screws, and other attaching hardware. Since gaskets tend to shrink after drying, check for and tighten loose nuts and cap screws securing mating surfaces.
- c. Carefully read all tags, decals, and markings on the pump assembly, and perform all duties indicated. Note the direction of rotation indicated on the pump. Check that the pump shaft rotates in the required direction.

CAUTION

Only operate this pump in the direction indicated by the arrow on the pump body and on the accompanying decal. Otherwise, the impeller could become loosened from the shaft and seriously damage the pump.

d. Check all lubricant levels and lubricate as necessary. Refer to the MAINTENANCE AND REPAIR section of this manual.

POSITIONING THE PUMP

Mounting


Locate the pump in an accessible place as close as practical to the liquid to be pumped. Level mounting is essential for proper operation. The pump may have to be supported to provide for level operation or to eliminate vibration.

Clearances

A minimum clearance of <u>18 inches</u> in front of the cover plate is required to permit removal of the cover and easy access to the pump interior.



Lifting



Make sure that hoists and other lifting equipment are of sufficient capacity to safely handle the pump assembly. If chains or cables are used, make certain that they are positioned so that they will not damage the pump, and so that the load will be balanced.

CAUTION

The pump assembly can be seriously damaged if the cables or chains used to lift and move the unit are improperly wrapped around it.

SUCTION AND DISCHARGE PIPING

Materials

Either pipe or hose may be used for suction and discharge lines, but hose used in suction lines must be the rigid-wall, reinforced type to prevent collapse under suction. Using pipe couplings in suction lines is not recommended.

Line Configuration

Keep suction and discharge lines as straight as possible to minimize friction losses. Make minimum use of elbows and fittings, which substantially increase friction loss. If elbows are necessary, use the long-radius type to minimize friction loss.

Connections to Pump

Never pull a pipe line into place by tightening the flange bolts. The connecting flange must be aligned exactly with the pump port. Lines near the pump must be independently supported to avoid strain on the pump which could cause serious vibration, decreased bearing life, and increased shaft and seal wear. Hose-type lines should have supports strong enough to secure the line when it is filled with liquid and under pressure.

Gauges

Most pumps are drilled and tapped for installing discharge pressure and vacuum suction gauges. If these gauges are desired for pumps that are not tapped, drill and tap the suction and discharge lines close to the pump before installing the lines.

Page 2 Section B.



SUCTION LINES

To avoid air pockets which could affect pump priming, the suction line must be as short and direct as possible. When operation involves a suction lift, the line must always slope upward to the pump from the source of the liquid being pumped; if the line slopes down to the pump at any point along the suction run, air pockets will be created.

Fittings

Suction lines should be the same size as the pump inlet. If reducers are used in suction lines, they should be the eccentric type, and should be installed with the flat part of the reducers uppermost to avoid creating air pockets. Valves are not normally used in suction lines, but if a valve is used, install it with the stem horizontal to avoid air pockets.

Sealing

All connections in the suction line should be sealed with pipe dope to ensure an airtight seal. Even a slight leak will affect priming, head, and capacity, especially when operating with a high suction lift. After installation, inspect the suction line carefully for potential leaks.

DISCHARGE LINES

Throttling Valves

If a throttling valve is desired, install it in the discharge line. Use a valve as large as the largest pipe in the line to minimize friction losses. Never install a throttling valve in the suction line.

Check Valves

A check valve in the discharge line is normally recommended, but is not necessary in low discharge head applications.

With high discharge heads, install a throttling valve and a check valve in the discharge line to protect the pump from excessive shock pressure and reverse rotation when it is stopped.

Bypass Lines

If it is necessary to permit the escape of air to atmosphere during initial priming or in the repriming cycle, install a bypass line between the pump and the discharge check valve. The bypass line should be sized so that it does not affect pump discharge capacity.

Either a Gorman-Rupp automatic air release valve—which will automatically open to allow the pump to prime, and automatically close when priming is accomplished—or a hand-operated shutoff valve should be installed in the bypass line.

Section B. Page 3




NOTE

The bypass line may clog frequently, particularly if the valve remains closed. If this condition occurs, either use a larger bypass line or leave the shutoff valve open during the pumping operation.

Do not terminate the discharge line at a level lower than that of the liquid being pumped unless a siphon breaker is used in the line. Otherwise, a siphoning action could result, causing damage to the pump.

SUCTION LINE POSITIONING

The depth of submergence of the suction line is critical to efficient pump operation. Figure 1 shows recommended minimum submergence vs. velocity.



VELOCITY IN FEET PER SEC. = $\frac{\text{QUAN. [G.P.M.] x .321}}{\text{AREA}}$ OR $\frac{\text{G.P.M. x .4085}}{\text{D}^2}$

Figure 1. Recommended Minimum Suction Line Submergence Vs. Velocity

Page 4 Section B.



Single Suction Lines

Install a single suction line a distance from the wall of the sump equal to one and one-half the size of the suction line. Liquid flow into a sump should never enter near the pump suction inlet because inflow will carry air down into the sump, and air entering the suction line will reduce pump efficiency.

If it is necessary to position an inflow pipe close to the suction inlet, install a baffle a distance from the suction inlet equal to one and one-half the size of the suction line (see figure 2). This baffle will allow entrained air to escape before the liquid is drawn into the suction line.




Figure 2. Eliminating Entrained Air Caused by a Fill Pipe

Multiple Suction Lines

When two suction lines are installed in one sump, separate the inlets by at least three times the diameter of the suction pipe. If the suction inlets are too close together, the flow paths may interact, reducing the efficiency of one or both pumps (see figure 3).




Figure 3. Using Two Pumps in the Same Sump




ALIGNMENT

The alignment of the pump and its power source is critical for trouble-free mechanical operation. In either a flexible coupling or V-belt driven system, the driver and pump must be mounted so that their shafts are aligned with and parallel-to each other.

NOTE

When mounted at the Gorman-Rupp factory, driver and pump are aligned before shipment. Misalignment can occur in transit and handling, however, and pumps should be checked, and realigned if necessary, before being put into operation.

Before checking alignment, tighten the foundation bolts. The pump casing feet and/or pedestal feet, and the driver mounting bolts should also be tightly secured.



Aligning Coupling Driven Pumps

In coupling applications, the axis of the drive unit must be aligned to the axis of the pump shaft in both the horizontal and vertical planes. Most couplings require a specific gap or clearance between the driving and the driven shafts. Refer to the coupling manufacturer's service literature for information.

To check non-spider type couplings, use a feeler gauge or a taper gauge between the coupling halves every 90 degrees. The coupling is in alignment when the hubs are the same distance apart at all points (see figure 5A).

To check spider insert type couplings, use calipers to measure the dimensions on the circumference of the outer ends of the coupling hub every 90 degrees. The coupling is in alignment when the hub ends are the same distance apart at all points (see figure 5B).



Figure 5A. Aligning Non-Spider Type Couplings



Figure 5B. Aligning Spider-Type Couplings



To check parallel adjustment, lay a straightedge across both coupling rims at the top, bottom, and side. The coupling is in horizontal parallel alignment when the straightedge rests evenly on both halves of the coupling. Use a feeler gauge between the coupling and the straightedge to measure the amount of misalignment.

Coupling and alignment adjustments may be made by loosening the hold-down bolts and shifting the driver and pump, or by shimming as required.

CAUTION

Adjusting the alignment in one direction may alter the alignment in another direction. Check each procedure after altering alignment.

Aligning V-Belt Driven Pumps

If V-belts and pulleys connect the drive unit to the pump, the unit and the pump must be parallel and the pulleys properly aligned. Use a straightedge along the sides of the pulleys to ensure alignment. For drive systems that employ two or more belts, make sure that the belts are a matched set; unmatched sets will result in accelerated belt wear (see figure 5C).





Figure 5C. Alignment of V-Belt Driven Pumps

Tighten the belts in accordance with the belt manufacturer's instructions. The belts will slip if they are too loose; there will be excessive power loss and possible bearing failure if they are too tight. Select pulleys that will provide the proper speed ratio. Overspeeding the pump may damage both pump and driver.

Drive Shaft Guards

Driver and shaft assemblies, couplings, and belts and sheaves mounted at the Gorman-Rupp factory are supplied with a guard for protection of personnel. Do not operate the pump without a guard.



Section B. Page 7

·			



OPERATION



PRIMING

Install the pump and piping as described in INSTALLATION. Make sure that the piping connections are tight, and that the pump is securely mounted. Check that the pump is properly lubricated (see LUBRICATION in MAINTENANCE AND REPAIR).

This pump is self priming, but the pump volute casing must first be filled with liquid if:

- 1. The pump is being put into service for the first time.
- 2. The pump has not been used for a considerable length of time.
- 3. The liquid in the volute casing has evaporated.

Once the volute casing has been filled, the pump will prime and reprime as necessary.

CAUTION

Never operate a self-priming pump unless the volute is filled with liquid. The pump will not prime when dry. Extended operation of a dry pump will destroy the seal assembly.

To fill the pump, remove the volute fill cover or fill plug at the top of the casing and add clean liquid until the pump is filled. Replace the fill cover or fill plug before operating the pump.

STARTING

Consult the operating manual furnished with the power source.

Rotation

The correct direction of pump rotation is indicated by an arrow on the pump body and on the accompanying decal. If the pump is operated in the wrong direction, the impeller could become loosened and the pump damaged.

Section C. Page 1



CAUTION

The impeller of the pump is threaded onto the pump shaft. Reverse rotation of the shaft can cause the impeller to unscrew and break the suction head or casing. Disconnect V-belts before checking for proper direction of motor rotation.

Before checking the pump motor rotation, remove the belt guard and V-belts. If the shaft or coupling is not visible, rotation can usually be determined by observing the motor cooling fan. If the rotation is incorrect have qualified personnel interchange any two of the three-phase wires to change direction.

Lines With a Bypass

If a bypass line has been installed, close the throttling valve in the discharge line, and open the bypass shutoff valve so that the pump will not have to prime against the weight of the liquid in the discharge line. When the pump has been primed, and liquid is flowing steadily from the bypass line, close the bypass shutoff valve and open the discharge throttling valve.

Lines Without a Bypass

Open all valves in the discharge line and start the power source. Priming is indicated by a positive reading on the discharge pressure gauge or by quieter operation. The pump may not prime immediately because the suction line must first fill with liquid. If the pump fails to prime within five minutes, stop it and check the suction line for leaks.

After the pump has been primed, partially close the discharge line throttling valve in order to fill the line slowly and guard against excessive shock pressure which could damage pipe ends, gaskets, sprinkler heads, and any other fixtures connected to the line. When the discharge line is completely filled, adjust the throttling valve to the required discharge flow rate.


Leakage

No leakage should be visible at pump mating surfaces, or at pump connections or fittings. Keep all line connections and fittings tight to maintain maximum pump efficiency.

Overheating

Overheating can occur if the valves in the suction or discharge lines are closed. Operating against closed valves could bring the liquid to a boil, build pressure, and cause the pump to rupture or explode. If overheating occurs, stop the pump and allow it to cool before servicing it. Refill the volute casing with cool liquid.





Pump Vacuum Check

Install a vacuum gauge in the system, using pipe dope on the threads.

The pump should pull a vacuum of 20 inches or more of mercury at operating speed with the suction line blocked. If it does not, check for air leaks in the seal or gaskets.

With the pump primed and at operating speed, and the suction line open, read the vacuum gauge. Shut off the pump, keep the vacuum line open, and read the gauge again to see if the vacuum remains at the maximum developed by the pump. If the vacuum falls off rapidly, an air leak exists. If the liquid level at the source of supply remains at a constant level, check to make certain that the air leak is not from the vacuum gauge connection.

STOPPING

After stopping the pump, disconnect the power source to ensure that the pump will remain inoperative.

In below freezing conditions, drain the pump to prevent damage from freezing. Also, clean out any solids by flushing with a hose. Operate the pump for approximately one minute; this will remove any remaining liquid that could freeze the pump rotating parts.

If the pump will be idle for more than a few hours, or if it has been pumping liquids containing a large amount of solids, drain the pump, and flush it thoroughly with clean water. To prevent large solids from clogging the drain port and preventing the pump from completely draining, operate the pump during the draining process. Clean out any remaining solids by flushing with a hose.



BEARING TEMPERATURE CHECK

Bearings normally run at higher than ambient temperatures because of heat generated by friction. Temperatures up to 160°F are considered normal for pump shaft bearings, and they can operate safely to at least 180°F.

Checking bearing temperatures by hand is inaccurate. They can be measured accurately by placing a contact-type thermometer against the housing. Record this temperature for future reference.

A sudden increase in bearing temperatures is a warning that the bearings are at the point of failing to operate properly. Make certain that the bearing lubricant is of the proper viscosity and at the correct level (see LUBRICATION in MAINTENANCE AND REPAIR). Bearing overheating can also be caused by shaft misalignment and/or excessive vibration.

When pumps are first started, the bearings may seem to run at temperatures above normal. Dynamic operation will bring the temperatures down to normal levels.



TROUBLESHOOTING

WARNING

Before attempting to open or service the pump:

- 1. Consult pump service manual.
- 2. Disconnect the power source to ensure that the pump will remain inoperative.
- 3. Allow pump to cool if overheated.
- 4. Close suction and discharge valves.
- 5. Drain pump.

Trouble	Possible Cause	Probable Remedy		
PUMP FAILS TO	Air leak in suction line.	Correct leak.		
PRIME	Lining of suction hose collapsed.	Replace suction hose.		
	Suction check valve clogged or binding.	Clean valve.		
	Leaking or worn seal or pump gasket.	Check pump vacuum. Replace leaking or worn seal or gasket.		
	Suction lift or discharge head too high.	Check piping installation and install bypass line if needed. See INSTALLATION.		
PUMP STOPS OR	Air leak in suction line.	Correct leak.		
FAILS TO DE- LIVER RATED FLOW OR PRESSURE	Suction intake not sub- merged at proper level or sump too small.	Check installation and correct as needed. Check submergence chart (Section B, page 4).		
	Lining of suction hose collapsed.	Replace suction hose.		
	Impeller or other wear- ing parts worn or damaged.	Check impeller clearance. Replace worn parts as needed.		
	Impeller clogged.	Free impeller of debris.		
	Pump speed too slow.	Check driver output; check belts or couplings for slippage.		
	Discharge head too high.	Install bypass line.		
	Suction lift too high.	Reduce suction lift.		






Trouble	Possible Cause	Probable Remedy
PUMP STOPS OR FAILS TO DE- LIVER RATED FLOW OR PRESSURE (cont)	Leaking or worn seal or pump gaskets.	Check pump vacuum. Replace leaking or worn seal or pump gaskets.
PUMP REQUIRES TOO MUCH POWER	Pump speed too high.	Check driver output; check that sheaves or couplings are correctly sized.
FOWER	Discharge head too low.	Adjust discharge valve.
	Liquid solution too thick.	Dilute if possible.
PUMP CLOGS FREQUENTLY	Discharge flow too slow.	Open discharge valve fully to increase flow rate, and run engine at maximum governed speed.
	Suction check valve clogged or binding.	Free valve, and clean or replace it.
EXCESSIVE NOISE	Cavitation in pump.	Reduce suction lift and/or friction losses in suction line.
	Pumping entrained air.	Locate and eliminate source of air bubble.
	Pump or drive not securely mounted.	Secure mounting hardware.
	Impeller clogged or damaged.	Clean out debris; replace damaged parts.
BEARINGS RUN TOO HOT	Bearing temperature is high, but within limits.	Check bearing temperature.
	Low or incorrect lubricant.	Check for proper type and level of lubricant.
	Suction and discharge lines not properly supported.	Check piping installation for proper support.
	Drive misaligned.	Align drive properly.



Basic Self-Priming Centrifugal Pump Model T6A3-B



The only moving parts of this pump are the impeller, seal rotating elements, and the shaft. The wear plate, impeller, and seal, which receive the most wear, are easily accessible and can be replaced without disturbing the piping. Maintenance and replacement of these three parts will maintain the peak operating efficiency of the pump.

WARNING

This pump is designed to pump materials which could cause serious illness or injury through direct exposure or emitted fumes. Wear protective clothing, such as rubber gloves, face mask, and rubber apron, as necessary before disassembling the pump or piping.

Section E. Page 1



SECTIONAL DRAWING




Figure 1. Pump Model T6A3-B



PARTS LIST

										· · ·
NO.		PART NUMBER	MATL CODE	NO. REQ	ITE NC		MODEL T6A3-B PART NAME	PART NUMBER	MATL	NO. REQ
1	VOLUTE CASING	10957-C	10010	1	24	L	OCKWASHER .	J-12	15991	8
2	ROTATING ASSY	10956-G		1	25	P	IPE PLUG	P-04	11990	1
3	NAMEPLATE	2613-D	13990	1	26	☆ F.	LAP VALVE ASSY	46411-064		1
4	DRIVE SCREW	BM-04-03	15990	4	27	SI	UCTION FLANGE	11402	10010	1
5 🕏	BEARING HOUSING	S-1676		1	28	V	ALVE PIN	11645	17010	1
	O-RING				29	☆sı	UCTION FLANGE	11402-G	21020	1
6	ROTATION DECAL	2613-CU	00000	1	1	G	ASKET			
7	HEX HD CAP SCREW	B-0806	15991	4	30	Α	CCESSORY PLUG	P-04	11990	1
8	LOCKWASHER	J-08	15991	4	31	Н	EX HD CAP SCREW	B-1208	15991	8
9 🕏	ROTATING ASSEMBLY	13131	17000	4	32	L	OCKWASHER	J-12	15991	8
	SHIM SET			,	33	D	ISCHARGE FLANGE	1758	10010	1
10 ☆	WEAR PLATE	46451-723	24150	. 1	34	☆D	ISCHARGE FLANGE	1679-GE	21020	1
11	VOLUTE DRAIN	P-16	11990	1	1	G.	ASKET			*
	PLUG		100		35	E,	YE BOLT	AR-1003½	15050	1
12 🕏	COVER O-RING	S-1676		1	36	P	IPE PLUG	P-04	11990	1
13	LOCKWASHER	J-06	15991	4	37		ILL COVER	40	11000	1
14	HEX NUT	D-06	15991	4		С	LAMP.BAR			
15	COVER HAND NUT	10701-A	15040	2	38	M	ACHINE BOLT	A-1014	15991	2
16	STUD	C-1211	15991	2	39	☆F	ILL COVER GASKET	50-G	19090	1
17	COVER ASSEMBLY	42111-905		1	40	F	ILL COVER	136	15000	1
18 🛱	COVER	10962-A	10010	. 1	1	_	LAMP SCREW			
19	WARNING PLATE	2613-EV	13990	1	41		ILL COVER ASSY	48271-010		1
20	DRIVE SCREW	BM-04-03	15990	4	42	☆F	ILL COVER	50	10010	1
21 🟚	PRESSURE RELIEF	26662-005		1	43		ARNING TAG	6588-BG		1
	VALVE				44	_	EAL WIRE	31311-002	17990	. 1
22	CAUTION DECAL	2613-FG		1	45	L	EAD SEAL	21188-002		-1
23	HEX HD CAP SCREW	B-1211	15991	8						

☆ Indicates parts recommended for stock

Note: This parts list applies to pumps from serial no. 574097N. Above serial numbers do not apply to pumps made in Canada.

CANADIAN SERIAL NO.

Section E.



SECTIONAL DRAWING




Figure 2. Rotating Assembly for Pump Model T6A3-B



PARTS LIST

ITEM	MODEL T6A3-B	PART	MATERIAL	NUMBER
NO.	PART NAME	NUMBER	CODE	REQUIRED
1	☆ IMPELLER	10958	11000	1
2	★ SEAL PLATE GASKET	10959-G	11000 20000	1
3	★ SEAL ASSEMBLY	12364-A	20000	1
4.	★ BALL BEARING	S-1080		1
5	BEARING HOUSING	10959-B	10010	1
6	★ VENTED SEAL CAVITY PLUG	10939-Б 4823-А	11990	1
7	★ BEARING HOUSING AIR VENT	S-1530	11990	1
8	REDUCER BUSHING	AP-0802	11990	1
9	★ BALL BEARING	S-1040	11330	1
10	★ BEARING CAP	10530	10010	1
11	★ IMPELLER SHAFT	10529	16040	.1
12	★ SHAFT KEY	N-0612	15990	1
13	★ OIL SEAL	S-1352	10000	1
14	★ SNAP RING	S-244		1
15	HEX HEAD CAP SCREW	B-0605	15991	4
16	LOCKWASHER	J-06	15991	4
17	★ BEARING CAP GASKET	10530-G	18000	1
18	☆ OIL SEAL	S-1352		1
19	STUD	C-0807	15991	1
20	LOCKWASHER	J-08	15991	4
21	HEX NUT	D-08	15991	4
22	★ SEAL PLATE	11837-E	10010	1
23	☆ IMPELLER CAP SCREW	DM-1004-S	15990	1
24	☆ IMPELLER WASHER	10278	15030	1
25	PIPE PLUG	P-12	11990	1
26	BEARING HOUSING DRAIN PLUG	P-08	11990	1
27	SEAL CAVITY DRAIN PLUG	P-08	11990	1
28	☆ OIL LEVEL SIGHT GAUGE	S-1471		1
29	☆ IMPELLER SHIM SET	37-J	17090	.1
30	☆ SHAFT SLEEVE	11876-A	16000	1
31	☆SHAFT SLEEVE O-RING	S-2088		1
32	☆ ROTATING ASSEMBLY SHIM SET	13131	17000	1
33	☆ BEARING HOUSING O-RING	S-1676		1

★ Indicates parts recommended for stock

Note: This parts list applies to pumps from serial no. 574097N. Above serial numbers do not apply to pumps made in Canada.



PUMP AND SEAL DISASSEMBLY AND REASSEMBLY

This pump requires little service due to its rugged, minimum-maintenance design. If it becomes necessary to inspect and/or replace the wearing parts, however, follow these instructions, which are keyed to the sectional views (see figures 1 and 2) and the accompanying parts lists.

Pump Disassembly

The impeller, wear plate, flap valve, and seal assembly are easily accessible and can be serviced by removing the cover plate (18, figure 1).

Disconnect the power source, making certain that it will remain inoperative while the pump is being serviced, and close all connecting valves. Remove the volute drain plug (11) to drain the pump.

Remove the hex head cap screws (7) securing the rotating assembly (2) to the volute casing (1). Separate the assemblies and remove the rotating assembly adjusting shims (9, figure 1 and 32, figure 2). For ease of reassembly, tag and tie the shims, or measure and record their thickness. Inspect the wear plate (10, figure 1) and replace it if scored or worn.

To loosen the impeller (1, figure 2), immobilize it by placing a block of wood between the vanes. Remove the impeller capscrew (23) and washer (24), and turn the shaft (11) counter to the direction of pump rotation. Unscrew the impeller from the shaft and remove the impeller adjusting shims (29). For ease of reassembly, tag and tie the shims, or measure and record their thickness. Replace the impeller if cracked or worn.

Seal Disassembly

Before removing the seal assembly, remove the seal cavity drain plug (27, figure 2) to drain the seal cavity. Clean and reinstall the seal cavity drain plug.

Carefully remove the seal spring seat, the shaft sleeve (30) and the stationary and rotating elements, using a stiff wire with a hooked end if necessary. Remove the shaft sleeve O-ring (31).

Clean the seal cavity and shaft with a soft cloth soaked in cleaning solvent.



Seal Reassembly

The seal is not normally reused because of the high polish on its lapped faces, but if it is necessary to reuse the old seal, wash all metallic parts in cleaning solvent and dry thoroughly.

Page 6 Section E.






Figure 3. 12364-A Seal Assembly

Inspect the seal components for wear, scoring, grooves, and other damage that might cause leakage. If any components are worn, replace the complete seal; never mix old and new seal parts. Replace the shaft sleeve O-ring and the shaft sleeve if there are nicks or cuts on the end.

CAUTION

This seal is designed for operation at temperatures not exceeding 160° F. Do not use at higher operating temperatures.

Lubricate the shaft sleeve O-ring with soft grease or oil. Install the shaft sleeve O-ring and the shaft sleeve, making certain that the O-ring is captured in the counterbore of the shaft sleeve, and that the sleeve is seated firmly on the shoulder of the shaft. Install the replacement seal as a complete unit.

Lubricate the bellows and O-rings with soft grease or oil when installing the seal, and place a drop of light lubricating oil on the lapped faces. Assemble the seal as shown in figure 3.

MAINTENANCE AND REPAIR



Pump Reassembly

Reinstall the impeller adjusting shims and the impeller. Reinstall the impeller washer and cap screw, and torque the cap screw to 90 ft-lbs. A clearance of .025 to .040 inch between the impeller and seal plate (22, figure 2) is necessary for maximum pump efficiency. Measure this clearance, and add or subtract impeller shims until it is reached. When the proper clearance is reached, remove the impeller cap screw, place "Never-Seez" compound or equivalent on the threads, and torque the cap screw to 90 ft-lbs.

Before reassembling the rotating assembly to the volute casing, replace the bearing housing O-ring (5, figure 1 and 33, figure 2).

Reinstall the rotating assembly adjusting shims, and reassemble the rotating assembly to the volute casing. A clearance of .010 to .020 inch between the impeller and the wear plate is also recommended for maximum pump efficiency. This clearance can be reached by adding or subtracting rotating assembly adjusting shims until the impeller binds against the wear plate when the shaft is turned. After the impeller binds, add .015 inch of shims.

LUBRICATION

Seal Assembly

Before starting the pump, remove the vented seal cavity plug (6, figure 2) and fill the seal cavity with approximately 40 oz. of SAE No. 30 non-detergent motor oil. Clean and reinstall the vented seal cavity plug.

Bearings

Under normal service, drain and refill the bearing housing with clean oil yearly. When oil is required, remove the bearing housing air vent (7, figure 2) and fill the bearing housing with approximately 32 oz. of SAE No. 30 non-detergent motor oil, or to the midpoint of the oil level sight gauge (28). Clean and reinstall the bearing housing air vent.

THE GORMAN-RUPP COMPANY AND GORMAN-RUPP OF CANADA LIMITED 12 MONTH LIMITED WARRANTY

EXTENT AND DURATION OF WARRANTY

Coverage: The Gorman-Rupp Company or Gorman-Rupp of Canada Limited (herein individually referred to as "GR") each individually warrant that its products and parts shall be free from defects in material and workmanship for twelve (12) months from the date of purchase by the original end user.

Exceptions: This Limited Warranty shall not apply to the following products and parts: engines, motors, trade accessories and other products, components or materials not manufactured by GR. With respect to submersible pumps, the pump and motor are an integral unit and are therefore warranted as a unit. However, with respect to the electrical components in submersible pumps, this warranty is valid **only** when electrical controls for the pump have been specified and/or provided by GR. Wear and tear on any product resulting from normal use is not covered by this Limited Warranty.

LIMITATIONS

GR'S SOLE AND EXCLUSIVE WARRANTY WITH RESPECT TO ITS PRODUCTS AND PARTS IS THIS LIMITED WARRANTY. THIS LIMITED WARRANTY IS IN LIEU OF ALL OTHER EXPRESS AND/OR IMPLIED WARRANTIES, INCLUDING IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR PARTICULAR PURPOSE.

EXCLUSIVE REMEDY AND DAMAGES

The sole and exclusive remedy for breach of this Limited Warranty by GR, and the entire extent of its liability for such breach or for damages arising and/or resulting from the use of the products and parts covered by this Limited Warranty shall be as follows:

1. Repair or replacement: If inspection shows that any GR product or part covered under this LimitedWarranty is defective in materials or workmanship, GR shall repair or replace the defective product or part at its option, without charge. You must have properly installed, maintained and used the product or part claimed to be defective in accordance with the maintenance schedule and/or manual which comes with the product. No allowance will be made for labor, transportation or other charges incurred by you in connection with such repair or replacement.

2. To obtain the above remedy:

- a) Immediately notify GR at the address below of the claimed defect in materials or workmanship and provide the serial number or date code of the product and/or part and provide a copy of the invoice or bill of sale referencing the product and/or part by no later than the expiration date of the Limited Warranty period.
- b) GR will advise whether inspection of the product and/or part will be necessary and whether and how repair or replacement will be effected. If inspection by GR is necessary, the product or part must be sent freight prepaid to GR at the address stated below. Return shipment of the repaired product or part will be F.O.B. the address stated below.
- 3. Damages: GR's liability for damages for breach of this Limited Warranty shall not exceed the amount of the purchase price of the product or part in respect to which damages are claimed. IN NO EVENT SHALL GR BE LIABLE FOR INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES FOR BREACH OF THIS LIMITED WARRANTY OTHER THAN AS STATED HEREIN.

Some states do not allow the exclusion or limitation of incidental or consequential damages. Accordingly, the above may not apply to you. This Limited Warranty gives you specific legal rights, and you may also have other rights which vary from state to state and province to province.

THE GORMAN-RUPP COMPANY P.O. BOX 1217 MANSFIELD, OH 44901-1217 Phone: (419) 755-1011 GORMAN-RUPP OF CANADA LIMITED 70 Burwell Road St. Thomas, Ontario N5P 3R7 Phone: (519) 631-2870