Use With: OM-03989 MR-03991



## PUMP MODEL RD3A32—BAR

MANUAL PART 2 of 3

PARTS
LIST
WITH
PERFORMANCE CURVE

THE GORMAN-RUPP COMPANY • MANSFIELD, OHIO

# Register your new Gorman-Rupp pump online at www.grpumps.com

Valid serial number and e-mail address required.

## **RECORD YOUR PUMP MODEL AND SERIAL NUMBER**

Please record your spaces provided b needs this information	elow. Your	Gorman-Rupp	distributor
Pump Model:			
Serial Number:			

RD SERIES PUMP PL—03992

## PERFORMANCE CURVE - SECTION A

## RECORDING MODEL AND SERIAL NUMBERS

Please record the pump model and serial number in the spaces provided below and in the separate <u>Installation/Operation Manual</u> accompanying your pump. Your Gorman-Rupp distributor needs this information when you require parts or service.

Pump Model:	
Serial Number:	

#### WARRANTY INFORMATION

The pump warranty is provided as part of Gorman-Rupp's support program for customers who operate and maintain their equipment as described in this manual and other accompanying literature. Please note that should the equipment be abused or modified to change its performance beyond the original factory specifications, the warranty will become void and any claim will be denied.

### PERFORMANCE CURVES

The performance curve on the following page is based on 70° F (21° C) clear water at sea level, corrected to 0.80 specific gravity, with minimum suction lift. Since pump installations are seldom identical, your performance may be different due to such factors as viscosity, specific gravity, elevation, temperature, and impeller trim.


If your pump serial number is followed by an "N", your pump is **NOT** a standard production model. Contact the Gorman-Rupp Company to verify performance or part numbers.



Pump speed and operating condition points must be within the continuous performance range shown on the curve(s).

PAGE A — 1 PART LIST MANUAL

PL-03992 RD SERIES PUMP



#### Performance Curve — Model RD3A32—BAR

PARTS LIST MANUAL PAGE A – 2


RD SERIES PUMP PL-03992


This Page Intentionally Blank

PAGE A – 3 PART LIST MANUAL

RD3A32-BAR В

> S/N 1281378 Up PUMP ISSUE 3





## THE GORMAN-RUPP COMPANY • MANSFIELD, OHIO

05/17/99

RD3A32-BAR

**S/N 1281378 Up PUMP ISSUE 3** 

## PARTS LIST Pump Model RD3A32—BAR

If your pump serial number is followed by an "N", your pump is **NOT** a standard production model. Contact the Gorman-Rupp Company to verify part numbers.


ITEM NO.	PART NAME	PART NUMBER	MAT'L CODE	QTY	ITEM NO.	PART NAME	PART NUMBER	MAT'L CODE	QTY
1 2 * 3 4 *	CONNECTOR	W01173-02 38623-530 25812-214 N0611	10140 13048  15990	1 1 1	24 * 25 26 27	PUMP CASING GASKET STUD HEX NUT RETURN TUBE	R12531 C0807 D08 46335-090	20000 15991 15991	1 12 12 1
5 6 7	DISCH TUBE ASSY NAME PLATE DRIVE SCREW	46335-091 2613DZ BM#04-03	13990 15990	1 1 2	28 29 30	BEARING HSG SUPPORT HEX HD CAPSCREW LOCKWASHER	R12852-01 B0805 J08	15990 15991 15991	1 2 2
8 9 10	LUBE DECAL BRG HOUSING ASSY PIPE PLUG	38816-081 44143-105 P06	  15079	1 1 1	31 32 33	FLAT WASHER MALE ELBOW HEX HD CAPSCREW	K08 25812-011 B0805	15991  15991	2 1 2
11 12 13 ** 14	SUCT TUBE ASSY DISCHARGE STICKER IMPELLER KEY LOCKWASHER	46335-076 6588BJ K79329-23 23962-506	  15990	1 1 1	34 35 ●	LOCKWASHER AIR RELEASE VALVE GF	J08 RP33-06B	15991 	2 1
15 16 17	IMPELLER NUT PIPE PLUG PIPE PLUG	K75776 P02 P02	15111 15079 15079	1 1 1	Ι	HOWN: DISCH CHK VALVE GSKT DISCH FLANGE GASKET INSTRUCTION TAG	11589GA N14147 38817-011	18000 18000	1 1 1
18 19 20 21	SUCTION STICKER PIPE PLUG CONNECTOR STRAINER	6588AG P02 25812-214 26841-094	15079 	1 1 1 1	OPTIO	NAL: COMPANION FLANGES (S	SUCT AND DIS		ı
22 23	CONNECTOR PIPE PLUG	25812-214 P02	 15079	1		-COMPANION FLG KIT STEEL TUBING KIT	K33850 48263-512		1 1


<sup>\*</sup> INDICATES PARTS RECOMMENDED FOR STOCK


- † ALL ROTO-PRIME® IMPELLERS ARE TRIMMED.
- $\bullet$   $\:$  SEE ACCOMPANYING LITERATURE FOR INDIVIDUAL PARTS, MAINTENANCE AND REPAIR.

B RD3A32-BAR

### S/N 1281378 Up PUMP ISSUE 3







## THE GORMAN-RUPP COMPANY • MANSFIELD, OHIO

RD3A32-BAR

**S/N 1281378 Up PUMP ISSUE 3** 

PARTS LIST 44143-105 Bearing Housing Assembly


ITEM NO.	PART NAME	PART NUMBER	MAT'L CODE	QTY	ITEM NO.	PART NAME	PART NUMBER	MAT'L CODE	QTY
1 *	SEAL ASSEMBLY	25271-921		1	24 *	LOCATING PIN	21154-666		1
2	SEAL RETAINING RING	24124-243		1	25 †	CENTER PLATE GASKET	N14145	18010	2
3	BEARING CAP	R12770-02	10010	1	26	PIPE PLUG	P06	15079	1
4	BEARING LOCK NUT	23962-011		1	27 *	CENTER PLATE GASKET	N14145	18010	1
5 <del>*</del>	BEARING CAP GASKET	N18938-01	18000	1	28	HEX HD CAPSCREW	B0612	15991	8
6	TAB WASHER	23962-511		1	29	LOCKWASHER	J06	15991	8
7 *	OUTBOARD BEARING	23282-011		1	30	DOWEL PIN	21133-073		2
8	AIR VENT	S1703		1	31 *	OIL SEAL	25227-240		1
9	BEARING HOUSING	W01172-03	11010	1	32	PIPE PLUG	P02	15079	1
10 <del>*</del>	IMPELLER SHAFT	T08467-02	15010	1	33 *	OIL SEAL	25227-240		1
11 *	BALL BEARING	23282-010		1	34	CONNECTOR	25812-214		1
12	BEARING RET RING	24124-245		1	35	HEX HD CAPSCREW	B0605	15991	4
13	PIPE PLUG	P02	15079	1	36	LOCKWASHER	J06	15991	4
14	AIR VENT	S2162		1	37	MALE ELBOW	25812-011		1
15 <del>*</del>	SPACER PLATE GASKET	N14144	18000	1					
16	SPACER PLATE	N14129-02	11010	1	OPTIO	NAL:			
17	PRESS REG SPRING CAP	K68064	15991	1		SST IMPELLER SHAFT	T08467-02	17080	1
18 <del>*</del>	SPRING CAP GASKET	K86067		1		TEFLON SEAL ASSY	25271-761		1
19 *	PRESS REG SPRING	K76301		1	OIL LUBE BEARING HOUSING ASSEMBLY				
20	BODY COVER	T07826-04	10140	1			44143-110		1
21 *	ROTOR WOODRUFF KEY	K61559	15990	1		INBOARD BEARING	S1088		1
22 <del>*</del>	ROTOR BLADE	K79300-22		6		OUTBOARD BEARING	S1077		1
23	GROUP GRIND	LK05418		1	I	OIL CUP	26713-051		1

<sup>\*</sup> INDICATES PARTS RECOMMENDED FOR STOCK

<sup>† 2</sup> GASKETS REQUIRED WHEN ROTOR OR SLIDE IS THICKER THAN CENTER PLATE.

<sup>•</sup> ALL OTHER COMPONENTS SAME AS STANDARD BEARING HOUSING ASSEMBLY.

S/N 1281378 Up PUMP ISSUE 3



## PARTS LIST LK05418 Group Grind

ITEM NO.	PART NAME	PART NUMBER	MAT'L CODE	QTY
1	CENTER PLATE	NOT AVAILABLE		1
2	ROTOR	NOT AVAILABLE		1
3	SLIDE	NOT AVAILABLE		1

**NOTE:** THE GROUP GRIND MUST BE REPLACED AS A COMPLETE UNIT: INDIVIDUAL PIECE PARTS ARE NOT SOLD SEPARATELY.

## THE GORMAN-RUPP COMPANY • MANSFIELD, OHIO

Page 120.3 A25

В

# For U.S. and International Warranty Information, Please Visit www.grpumps.com/warranty or call:

U.S.: 419-755-1280 International: +1-419-755-1352

For Canadian Warranty Information,
Please Visit www.grcanada.com/warranty
or call:
519-631-2870