PUBLICATION NUMBER PL--04205--01

Pump Issue 1 May 16, 1995

Supersedes: OM--02806--01

Use With: OM--04151

MR--04269



# PUMP MODEL S3B65-E6 575/3

MANUAL PART 2 of 3

PARTS
LIST
WITH
PERFORMANCE CURVE

S SERIES PUMP PL--04286

#### PERFORMANCE CURVE - SECTION A

# RECORDING MODEL AND SERIAL NUMBERS

Please record the pump model and serial number in the spaces provided below and in the separate <u>Installation/Operation Manual</u> accompanying your pump. Your Gorman-Rupp distributor needs this information when you require parts or service.

Pump Model:		
Serial Number:		

#### WARRANTY INFORMATION

The pump warranty is provided as part of Gorman-Rupp's support program for customers who operate and maintain their equipment as described in this manual and other accompanying literature. Please note that should the equipment be abused or modified to change its performance beyond the original factory specifications, the warranty will become void and any claim will be denied.


#### PERFORMANCE CURVES

The performance curves on the following page are based on 70° F (21° C) clear water at sea level. Since pump installations are seldom identical, your performance may be different due to such factors as viscosity, specific gravity, elevation, temperature, and impeller trim.

If your pump serial number is followed by an "N", your pump is **NOT** a standard production model. Contact the Gorman-Rupp Company to verify performance or part numbers.




Pump speed and operating condition points must be within the continuous performance range shown on the curve(s).



Performance Curve – Model S3B65–E6 575/3

PAGE A -- 1 PART LIST MANUAL



# THE GORMAN-RUPP COMPANY • MANSFIELD, OHIO


Printed in U.S.A.

### S/N 1199517 Up PUMP ISSUE 1

If your pump serial number is followed by an "N", your pump is **NOT** a standard production model. Contact the Gorman-Rupp Company to verify part numbers.

ITEM NO.	PART NAME	PART NUMBER	MAT'L CODE	QTY	ITEM NO.	PART NAME	PART NUMBER	MAT'L CODE	QTY
1	SUCTION HEAD	38246-032	1718H	1	37	BRG SPRING WASHER	S1554		1
2 *	IMPELLER	38618-701	1718H	1	38 *	UPPER BALL BEARING	S1044		1
3 <del>*</del>	LOWER SEAL ASSY	46512-071		1	39	STATOR ASSY	47113-862		1
4 *	UPPER SEAL ASSY	S1832		1	40 *	ROTOR & SHAFT ASSY	47112-810		1
5	SEAL PLATE	38272-351	1718H	1	41	ALLEN HD SETSCREW	GA0603	15990	1
6 <del>*</del>	MOTOR HSG O-RING	25154-270		1	42	SOCKET HD PIPE PLUG	PC04	17090	1
7	FH MACH SCREW	Y#10-03	17090	2	43	INTERMEDIATE	38311-803	13040	1
8 *	INTERMEDIATE O-RING	25152-258		1	44	MTR CAVITY DRAIN PLUG		17090	1
9	MOTOR BUSHING	31173-017	23010	1	45	SEAL CVTY DRAIN PLUG	PC04	17090	1
10 *	LOWER BALL BEARING	23425-007		1	46 *		25154-261		1
11	BEARING SNAP RING	S1831		1	47	STUD	C0610	17090	6
12	NAME PLATE	38818-039	17090	1	48	LOCKWASHER	J06	17090	6
13	DRIVE SCREW	BM#04-03	17090	6	49	HEX NUT	D06	17090	6
14	MOTOR HOUSING	38311-033	17070	1	50 51	STRAINER ASSY	46611-010 KB08	24170 17090	1
15	SHAFT SLEEVE	13878	17090	1	51 52	FLAT WASHER IMPELLER NUT	22561 – 165	17090	1 1
16 *	IMPELLER ADJ SHIM SET	2Y	17090	1		IMPELLER KEY	N0302-1/2	17090	1
17 <del>*</del>	SEAL SPRING RETAINER	8793	17090	1	53 <sup>1</sup>	NYLOCK CAPSCREW	BT0806	17090	3
18	SEAL RETAINING RING	24124-332		1	34	NTLOCK CAPSCREW	D10000	17090	3
19	HOISTING BAIL	31926-009	17130	1	NOT 9	HOWN:			
20	HEX NUT	D08	17090	1	11010	QT. SUB PUMP OIL	9568		1
21	PIPE CAP	25471 – 223		1		CONTROL BOX	47631 – 141		1
22	HVY PIPE NIPPLE	THA0608	17090	1		MOTOR VOLTAGE TAG	38816-128		1
23	STUD	C0806	17090	1		IMPELLER PULLER	10285		1
24	COUPLING NUT	31811-019	17130	1		CABLE TIE	27111-212		1
25	HEX NUT	D08	17090	1					
26	STUD	C0809	17090	3	OPTIC				
27	HEX NUT	D08	17090	3	*	REPAIR GASKET SET	11000AA		1
28	DISCHARGE FLANGE	38641-006	17070	1		STAGING ADAPTOR	48272-015		1
	DISCH FLANGE GSKT	38687 – 045	19370	1		-FLANGE	38641-006	17070	1
	RELIEF VALVE ASSY	46431 – 646		1		-GASKET	38687 – 045	19370	1
31	TERM HSG/CABLE ASSY	47367-042	47000	1					
32	STUD	C0513	17090	4		LIQUID LEVEL DEVICES:	CDD40 00	CDD 42	0/1
33	LOCKWASHER	DOES NOT A		4		DIAPHRAGM TYPE	GRP48-03 (	or GRP48-	
34 35	HEX NUT	D05 D0ES NOT A	17090	4		FLOAT TYPE	27471 – 180		1
35 36	CONNECTOR HEAT SHRINK TUBE	DOES NOT A				120V LIQ LVL CONTROL	47631-072		1
30	LILAT SUKTINE TOBE	DOES NOT F	AFFLY		ı	120V LIQ LVL CONTRUL	4/031-0/2		ı

<sup>\*</sup> INDICATES PARTS RECOMMENDED FOR STOCK



# THE GORMAN-RUPP COMPANY • MANSFIELD, OHIO

Printed in U.S.A.

S/N 1199517 Up PUMP ISSUE 1

## **Terminal Housing**

If your pump serial number is followed by an "N", your pump is **NOT** a standard production model. Contact the Gorman-Rupp Company to verify part numbers.

ITEM NO.	l	PART NAME	PART NUMBER	MAT′L CODE	QTY			
NO.		17401 147401	NUMBER	CODE	211			
1	*	LOWER TERMINAL PLATE GASKET	38687 – 525	19370	1			
2		HEX NUT	D#10	14990	3			
3		HEX NUT	D#10	14990	3			
4		ROUND HEAD MACHINE SCREW	X#10-02	14990	1			
5		T TYPE LOCK WASHER	AK#10	15991	1			
6		INFORMATION PLATE	38816-047	17050	1			
7		DRIVE SCREW	BM#04-03	17090	4			
8		TERMINAL HOUSING	38381 – 233	17070	1			
9	*	CABLE GRIP	DOES NOT APPLY					
10		TERMINAL CAP	38381-626	17070	1			
11	*	CABLE ASSEMBLY	47351-055		1			
12		STUD	C0606	17090	2			
13		HEX NUT	D06	17090	2			
14	*	GLAND BUSHING	10758F	19540	1			
15		HEAT SHRINK TUBE	31412-053	19530	3			
16	*	UPPER TERMINAL PLATE GASKET	38687-525	19370	1			
17		TERMINAL PLATE	38713-008	23010	1			
18		TERMINAL	11181	14100	3			
19		ROUND HEAD NYLOK MACHINE SCREW	GA#10-01S	15991	3			
20		DYNA-SEAL WASHER	S1590		3			
21		1 OZ RTV SEALANT	18771 – 106		1			
NOT SHOWN:								
		MOTOR PLATE	10436	17050	1			
		DRIVE SCREW	BM#04-03	17090	4			
OPTIONAL:								
		HEAT SHRINK TERMINAL KIT	48315-003		1			

<sup>\*</sup> INDICATES PARTS RECOMMENDED FOR STOCK

# For U.S. and International Warranty Information, Please Visit www.grpumps.com/warranty or call:

U.S.: 419-755-1280 International: +1-419-755-1352

For Canadian Warranty Information,
Please Visit www.grcanada.com/warranty
or call:
519-631-2870